

#### Note!

Please note that there can be small differences between your product and the images in these instructions.

#### Note!

Please note that during storage and transport, especially at high ambient temperature, some of the oil and grease used for assembly may leak and stain the packaging. This will not cause damage to the product, wipe off the excessive oil or grease with a cloth.

**Mounting Instructions** 

Kit Contents				
Description	Part No	Pcs		
Shock absorber	DMX 0216	1		
Spring clip	15087-08	1		
Owner's manual	07253-05	1		
Sticker Öhlins		1		
Sticker service schedule	15211-01	1		
MX fork & shock				

#### Note!

No spring included in this kit. See the spring guide in this folder or contact an Öhlins dealer for advice.

#### Note!

Before you install this product, check the kit contents. If anything is missing, please contact an Öhlins dealer.

#### **∆** Warning!

Before you install this product, read the Öhlins Owner's manual. This product is an important part of the vehicle and the vehicle stability.

## TTX Flow shock absorber for Kawasaki KX 450

DMX 0216

## OHLINS ADVANCED SUSPENSION TECHNOLOGY

# **MOUNTING INSTRUCTIONS**

### Install the Shock Absorber

### A Warning!

We strongly recommend to let an Öhlins dealer install this product.

### A Warning!

If you work with a lifted vehicle, make sure that it is safely supported to prevent it from tipping over.

#### Note!

When you work with this product, see the vehicle service manual for vehicle specific procedures and important data.

#### Note!

Before you install this product clean the vehicle.

#### 1

Put the motorcycle on a work stand so that the rear wheel barely touches the ground.

#### 2

Refer to the vehicle manual to remove the standard shock absorber.

#### 3

We recommend to reroute the cable harness between the shock absorber and air filter box in order to access all adjusters properly and to not interfere with the cable harness. Picture 1 shows the standard cable routing and picture 2 shows our suggested cable routing.

#### 4


Refer to the vehicle manual to install the Öhlins shock absorber.


#### Note!

Lower the vehicle so that the suspension is slightly compressed before you tighten the screws.

### Caution!

Make sure that you tighten all screws to the correct torque and that nothing fouls or restricts movement of the shock absorber/front fork/ steering damper when the suspension is fully compressed or extended.





Cable tie added here.

# **MOUNTING INSTRUCTIONS**

# **SETUP DATA**

Length	453	mm
Stroke	136	mm
Spring preload approx.	6 (3)	mm (turns)
Compr. low speed	6	clicks
Compr. high speed	8	clicks
Rebound	9	clicks

Free Sag and Ride Height			
R1-R2	40±5	mm	
R1-R3	105±5	mm	

# **SPRING GUIDE**

Kawasaki KX 450				
Rider's weight*	Spring	Spring rate		
kg/pounds	part no	N/mm		
60/132	06310-09	50		
65/143	06310-09	50		
70/154	06310-10	52		
75/165	06310-10	52		
80/176	06310-11	54		
85/187	06310-11	54		
90/198	06310-12	56		
95/209	06310-12	56		
100/220	06451-13	58		
105/231	06451-13	58		
110/242	06451-14	60		
115/253	06451-15	62		

\*Rider's weight: Rider wearing proper riding gear. Make sure you know your total weight with riding gear. Riding gear weighs between 5 and 15 kg.

Öhlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur. To find the latest information contact an Öhlins distributor. Please contact Öhlins if you have any questions regarding the contents in this document. Part no. MI\_DMX 0216\_0 Issued 2024-05-06

© Öhlins Racing AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited. Öhlins Racing AB Box 722 S-194 27 Upplands Väsby, Sweden Phone +46 8 590 025 00 fax +46 8 590 025 80



### www.ohlins.com