

Installation instructions

Akrapovič Exhaust System

Racing and Evolution

for the

BMW S1000R





Congratulations on purchasing the Akrapovič exhaust system. The Akrapovič exhaust system is a product of Akrapovič d.d., Malo Hudo 8a, 1295 Ivančna Gorica, Slovenia ("Akrapovič").

Please read this entire installation manual carefully prior to installing and using the Akrapovič exhaust system.

Akrapovič exhaust system should only be installed by persons skilled in motorcycle exhaust system installation and performance. The instructions provided in this manual should be followed to ensure proper installation and safe use of the Akrapovič exhaust system. Akrapovič and/or its partners shall not be held liable for any damage or personal injury (including direct, indirect, or consequential damage) sustained as a result of improper installation of the Akrapovič exhaust system or its use and maintenance contrary to the instructions and warnings contained herein.

If you have any questions regarding the installation and/or proper use of the Akrapovič exhaust system or this manual, please contact your local Akrapovič partner.

For more information on the Akrapovič exhaust systems, see the official Akrapovič website at: http://www.akrapovic.com

GENERAL INFORMATION

Your safety is our number one priority. Please ride your motorcycle responsibly, safely and always obey local traffic rules.

All statements made with regard to the exhaust system's compliance are made in respect of the exhaust system "as is". Any modifications of the Akrapovič exhaust system or its improper installation, use or maintenance that is not in accordance with this Installation manual, may result in severe damage to the exhaust system and/ or engine, as well as personal injury, and may affect the exhaust system's compliance with the legal requirements, such as exhaust system's air and/ or noise emissions (as an example, the motorcycle may not be suitable for use on public roads any longer), as well as warranty coverage.

The exhaust system may only be used in accordance with relevant laws and regulations, including state and federal, where applicable.

Damage caused by improper installation, use and maintenance of the Akrapovič exhaust system is not covered by the Akrapovič warranty. Please refer to the enclosed warranty with regard to the terms of our warranty.

Technical specifications of Akrapovič exhaust systems and related products are subject to change without notice.

COPYRIGHT AND OTHER RIGHTS NOTICE

The Akrapovič trademark, including corporate logos and emblems, are subject to copyright as well as trademark rights of Akrapovič, its licensors, or third persons authorizing Akrapovič to use them.

Any reproduction, technical or other manipulation, translation, or other use of the copyright and/or trademark rights contained herein is prohibited without the explicit prior written consent of Akrapovič. The same especially applies to the entire contents of this manual and/or any of its parts, including but not limited to technical specifications, instructions, graphs, photographs, and so on included in this manual.


The shape of the exhaust system is protected under a registered Community Design No. RCD 002747329-0001.

Akrapovič takes all copyright and other rights infringement cases under serious consideration. If you have any reason to believe that your exhaust system is not an original Akrapovič product, please contact our local partners or Akrapovič at info@akrapovic.com.

SAFETY AND COMPLIANCE WARNING, PLEASE READ CAREFULLY

BEFORE REMOVING THE STOCK EXHAUST SYSTEM AND BEGINNING THE INSTALLATION OF YOUR NEW AKRAPOVIČ EXHAUST, PLEASE MAKE SURE THAT ALL ITEMS LISTED BELOW ARE VERIFIED:

- THIS MANUAL IS SPECIFIC TO THE MOTORCYCLE INDICATED ON THE COVER PAGE, FOR WHICH IT IS
 DESIGNED. INSTALLATION PROCEDURES VARY DEPENDING ON THE TYPE OF MOTORCYCLE. PLEASE
 VERIFY THAT THE AKRAPOVIČ EXHAUST SYSTEM AND THIS INSTALLATION MANUAL CORRESPOND
 TO THE TYPE OF YOUR MOTORCYCLE.
- THE EXHAUST SYSTEM CAN GET EXTREMELY HOT DURING AND AFTER IT IS USED. MAKE SURE NOT TO
 TOUCH THE EXHAUST SYSTEM UNTIL IT IS COMPLETELY COOL. ALLOW THE EXHAUST AND ENGINE TO
 COOL DOWN BEFORE BEGINNING INSTALLATION OR ANY OTHER WORK ON THE EXHAUST SYSTEM.
- MAKE SURE THE MOTORCYCLE IS SECURELY POSITIONED TO PREVENT TIPPING OVER AND DAMAGE TO YOURSELF AND OTHERS, OR THE MOTORCYCLE.
- PLEASE CHECK THE PARTS YOU RECEIVED AGAINST THE PARTS LIST AVAILABLE ON OUR WEBSITE
 (PLEASE USE THE QR CODE ON THE FRONT PAGE OR LOOK FOR "SCHEMATIC VIEW" IN THE
 RESPECTIVE PRODUCT PAGE ON WWW.AKRAPOVIC.COM). MAKE SURE THAT YOU HAVE ALL THE
 PARTS NECESSARY FOR THE INSTALLATION OF YOUR NEW AKRAPOVIC EXHAUST SYSTEM. IF ANY
 OF THE PARTS IS MISSING, PLEASE DO NOT PROCEED WITH UNINSTALLING YOUR STOCK EXHAUST
 SYSTEM/ INSTALLING THE AKRAPOVIC EXHAUST SYSTEM AND CONTACT THE RETAILER WHERE YOU
 PURCHASED THE AKRAPOVIC EXHAUST SYSTEM.
- ALWAYS SECURE YOUR MOTORCYCLE'S GROUND CLEARANCE. FOR ADVANCED USERS, WE RECOMMEND YOU CHECK THE MOTORCYCLE SPRING PRELOAD SETTINGS TO OPTIMIZE GROUND CLEARANCE WHERE POSSIBLE.
- EVERY EXHAUST SYSTEM MUFFLER HAS ITS UNIQUE SERIAL NUMBER, WHICH IDENTIFIES THE
 AUTHENTICITY OF THE PRODUCT. YOU CAN FIND THE SERIAL NUMBER ON THE MUFFLER'S INLET
 PIPE. PLEASE REFER TO THE PICTURE BELOW. PLEASE VERIFY THAT YOUR EXHAUST SYSTEM IS
 AN ORIGINAL AKRAPOVIČ PRODUCT. IF YOU HAVE ANY DOUBTS, PLEASE CONTACT THE RESELLER
 WHERE YOU PURCHASED THE EXHAUST SYSTEM OR AKRAPOVIČ PARTNERS. THIS MANUAL, ANY
 CERTIFICATES AND AKRAPOVIČ WARRANTY APPLY TO ORIGINAL PRODUCTS ONLY.





SERIAL NUMBER POSITION

NOISE AND EMISSION WARNINGS

General warning

Because of the world-wide distribution of Akrapovič d.d. products, neither Akrapovič d.d. nor any of its subsidiaries make any representation that the products comply with the air and/or noise emissions laws, or labeling laws, of any jurisdiction. The purchasers are entirely responsible for informing themselves of the applicable laws where the products are to be used and to comply with those law.

Although legal compliance of Akrapovič products in a specific country should be determined by the user, you can find some basic guidance on compliance of your Akrapovič exhaust system with various legal requirements on the product-related part of our website (please use the QR code on the front page or look for the respective product page on www.akrapovic.com). For EC and ECE type approvals, please refer to the certificate enclosed to your product.

USA WARNING

Various U.S. states and the U.S. federal government have individual laws regulating the use of aftermarket exhaust parts and systems, especially as those parts and systems modify, remove, or replace original equipment catalysts. Please consult the appropriate laws in your area before installing any aftermarket part or system on your vehicle to ensure compliance with all applicable laws. Neither Akrapovic d.d. nor any of their subsidiaries or the sellers of the parts or systems make any representation that any of their parts or systems comply with any such laws.

CALIFORNIA WARNING

California laws prohibit the use of any aftermarket exhaust part or system that modifies, removes or replaces original equipment catalysts unless the California Air Resources Board has issued an Executive Order regarding such part or system or unless the part or system is exempted by being used only on racing vehicles on closed courses. Neither Akrapovic d.d. nor any of their subsidiaries make any representation that any of their parts or systems has received such an Executive Order or that any of their parts or systems conform with the racing vehicles exemption. The purchasers are entirely responsible for informing themselves of applicable California laws and to comply with those laws.

GENERAL NOTE

Photographs and other illustrations in this manual are symbolic and are intended to help represent individual steps for proper installation and use, as well as for a general overview. The actual component parts of the Akrapovič exhaust system may not entirely correspond to the photographs and other illustrations.

SYMBOLS

The following symbols are used throughout these installation instructions:



TOOLS AND PROTECTIVE EQUIPMENT REQUIRED



TIGHTENING TORQUE



LUBRICATION



HAND TIGHTEN



INSTALLATION TIP



CAUTION OR IMPORTANT

USE BOLT SEALANT



Apply 3 to 4 small drops of bolt sealant onto the cleaned and degreased threads before tightening the bolts.

WARNING! Avoid contact with skin, eyes and mucous membranes. Do not inhale fumes. Keep out of reach of children.



USE ANTI-SEIZE LEAD-FREE COPPER PASTE (black tube)

Provides trouble-free and long-lasting protection against seizing, corrosion and rusting of bolts, threaded ends, nuts, joints, etc. Also protects against vibration, wear and impact.

WARNING! Avoid eye contact. Keep out of reach of children.



USE ANTI-SEIZING GREASE (white tube)

Prevents seizing, corrosion and excessive wear between the titanium components of your exhaust system.

WARNING! Avoid eye contact. Keep out of reach of children.

Tools & equipment

- Torx 20 wrench
- Torx 25 wrench
- Torx 27 wrench
- Torx 30 wrench
- Torx 45 wrench
- · T- handle swivelling Torx 30 wrench
- · T- handle swivelling Torx 27 wrench
- · Combination 10 mm wrench
- Combination 17 mm wrench
- · Ratchet combination 10 mm bi-hex wrench
- T-handle 12 mm wrench
- Spring puller
- · Cutting nippers
- Flat nose pliers
- Flat screwdriver

PARTS LIST

The following parts should be found in the box:

- Installation Manual
- Homologation certificate/ compliance documents if applicable
- Warranty
- Fitting material
- Muffler and pipes

Detailed list of parts can be found on the Akrapovič website (please use the QR code on the front page or look for "Schematic view" in the respective product page on www.akrapovic.com).

REMOVAL OF STOCK EXHAUST SYSTEM:

The process of uninstalling the original exhaust system may vary depending on the existing exhaust system. Please follow the original exhaust system manufacturer's instructions for uninstalling the original exhaust system.

If you for any reason decide otherwise, please note that any information provided in this respect herein should be considered as general information provided for your convenience only. Akrapovič shall not assume any liability or responsibility with regard to uninstalling your existing exhaust system, warranty coverage of such exhaust system or vehicle or their further fitness for use.

In case your Akrapovič exhaust system may not be used on certain roads or under certain conditions, please keep the stock or other exhaust system that you can use in such circumstances legally.

ECU fuel-mapping enrichment

Please make sure that any ECU fuel-mapping enrichment is compliant with relevant laws, including state and federal, where applicable. Akrapovič makes no representation or warranty with regard to legal compliance, noise or gas emissions in case of ECU fuel-mapping enrichment.

Evolution and Racing

For perfect performance, throttle response and durability of the engine, the Akrapovič Evolution or Racing exhaust system must be used in combination with ECU fuel mapping enrichment provided by a professional, to avoid severe engine damage or breakdown, which could result in injury.



REMOVAL OF STOCK EXHAUST SYSTEM:


- Put the motorcycle on a side stand, we recommend a central racing stand. Make sure, that surface is solid and flat. Loosen the marked clamp, unscrew the muffler's bracket bolt and remove the muffler with heat shield off the motorcycle (Figure 1).
- Į IMPORTANT: be careful not to damage any part of the motorcycle during this process!




- 3. Unscrew the right foot peg and move it out of the way (Figure 2).
- IMPORTANT: be careful not to damage any part of the motorcycle during this process!




- 4. Unscrew the marked bolts on both sides of the motorcycle and carefully remove the lower and middle parts of the cowling off the motorcycle (Figure 3).
 - IMPORTANT: be careful not to damage any part of the motorcycle during this process!



- 5. Undo the marked snap rings, unscrew the marked bolt and carefully remove the radiators' bracket off the motor-cycle (Figure 4, 5).
- IMPORTANT: be careful not to damage any part of the motorcycle during this process!



🔀 AKRAPOVIĈ




- 6. Unscrew the lambda sensors (Figure 6).
- IMPORTANT: make sure not to damage the lambda sensors' electrical leads during this process!




- 7. Unscrew the marked bolt and carefully move the expansion tank out of the way (Figure 7).
- ! IMPORTANT: make sure, not to damage or disconnect the cooling system tubes!




- 8. Unscrew all flange nuts (Figure 8).
- ! IMPORTANT: be careful not to damage the radiator or any other part of the motorcycle during this process!




- 9. Undo the spring clip, remove the exhaust valve's cover, unscrew the marked cables' nuts and remove the cables off the valve (Figure 9, 10).
- IMPORTANT: be careful not to damage any part of the motorcycle during this process!





- 10. Unscrew the market bolts and carefully remove the stock exhaust off the motorcycle (Figure 11, 12).
- ! IMPORTANT: support the stock exhaust during this procedure or it may fall of and damage you or the motor-cycle!







- 11. Unscrew the rear brake reservoir's bracket (Figure 13).
- ! IMPORTANT: be careful not to damage any part of the motorcycle during this process!




- 12. Unscrew the rear brake's reservoir and carefully move the reservoir and bracket out of the way (Figure 14).
- ! IMPORTANT: be careful not to damage any part of the motorcycle during this process!





- 13. Unscrew the exhaust valve's servo motor, undo the electrical connector and carefully remove the servo motor with cables off the motorcycle (Figure 15, 16).
- IMPORTANT: be careful not to damage any part of the motorcycle during this process!







- 14. Unscrew the servo motor's cover, remove the cables and reinstall the cover (Figure 17, 18, 19).
- ! IMPORTANT: be careful not to damage the servo motor during this process!







- 15. Reconnect and reinstall the servo motor (Figure 20). Assemble the rear brake reservoir's bracket and reservoir in the reverse order from the order in which they were removed; check vehicle manufacturer manual for tightening torques.
- ! IMPORTANT: be careful not to damage any part of the motorcycle during this process!




- 16. Reinstall the right foot peg (Figure 21).
- ! IMPORTANT: be careful not to damage any part of the motorcycle during this process!




INSTALLATION OF THE AKRAPOVIČ EXHAUST SYSTEM:

- 1. Set up and hand tighten the flanges together with the springs and sleeves onto the cylinder head, using stock nuts; make sure you orient the flanges and springs as shown (**Figure 22, 23**).
- ! IMPORTANT: do not fully tighten the flanges yet!
- > INSTALLATION TIP: use new stock exhaust port gaskets.






- 2. Insert the headers into the sleeves, attach the springs and tighten the flanges to specified torque (Figure 24).
- IMPORTANT: before tightening the nuts, make sure, that springs pull the header tubes all the way into the sleeves use rubber mallet if necessary to tap the connections into place!
- IMPORTANT: be careful not to damage the radiator or any other part of the motorcycle during this process!




🕶 AKRAPOVIĆ


- 3. Slide the collectors onto the header tubes and attach the springs (Figure 25).
- IMPORTANT: make sure, that springs pull the collectors all the way onto the headers use rubber mallet if necessary to tap the connections into place!
- INSTALLATION TIP (for Evolution exhaust system only): coat the interior side of the inlet bushes of the titanium collectors with Akrapovič ceramic anti-seizing grease (white tube).



- 4. Slide the link pipe onto the collectors and attach the springs (Figure 26).
- ! IMPORTANT: make sure, that springs pull the link pipe all the way onto the collectors use rubber mallet if necessary to tap the connections into place!
- INSTALLATION TIP (for Evolution exhaust system only): coat the interior side of the input bushes of the titanium link pipe with Akrapovič ceramic anti-seizing grease (white tube).



- 5. Tighten both lambda sensors into the collectors and reinstall radiator bracket in the reverse order from the order in which they were removed **(Figure 27)**.
- ! IMPORTANT: make sure not to damage the sensors' electrical leads during this procedure!



- . Unscrew the right passenger's foot rest off the sub frame and disassemble the foot rest (Figure 28).
- IMPORTANT: be careful not to damage any part during this process!



🔀 AKRAPOVIĆ

- 7. Attach the additional Akrapovič stainless steel bracket to the passengers foot rest, using Akrapovič nut, bolt and washer (Figure 29, 30).
- ! IMPORTANT: be careful not to damage any part during this process!






- 8. Reinstall the right passenger's foot rest onto the sub frame (Figure 31).
- IMPORTANT: be careful not to damage any part of the motorcycle during this process!



- 9. Correctly position the carbon-fiber clamp and slide it onto the muffler bear in mind the **right offset** of the clamp; position the muffler correctly and slide it onto the outlet side of the link pipe, attach the springs and hand tighten clamp onto the muffler's bracket (**Figure 32**).
- ! IMPORTANT: open the clamp slightly wider than the diameter of the outer sleeve of the muffler do not scrape it along the muffler outer sleeve!
- INSTALLATION TIP (for Evolution exhaust system only): coat the interior side of the inlet bush of the muffler with Akrapovič ceramic anti-seizing grease (white tube).



- 10. Align the muffler in respect to the motorcycle and tighten the clamp to the muffler bracket (Figure 33).
- ! IMPORTANT: before tightening, make sure that springs pull the muffler all the way onto the link pipe use rubber mallet if necessary to tap the connection into place!



- 11. Assemble the cowlings in the reverse order from the order in which they were removed (Figure 34).
- > INSTALLATION TIP: check vehicle manufacturer manual for tightening torques!
- ! IMPORTANT: be careful not to damage any part of the motorcycle during this process!



INSTALLATION OF THE AKRAPOVIČ OPTIONAL MUFFLER BRACKET:


- 1. Unscrew the passenger's foot rests on both sides of the motorcycle (Figure 35).
- ! IMPORTANT: do not carry passengers in case of installation of carbon fiber bracket!



- 2. Install the Akrapovič carbon fiber muffler's bracket, using stock bolts (Figure 36).
- IMPORTANT: do not carry passengers in case of installation of carbon fiber bracket!



- 3. Attach the muffler's clamp onto the bracket as shown, using bolt, washers and nut from bracket's installation kit (Figure 37).
- ! IMPORTANT: do not carry passengers in case of installation of carbon fiber bracket!



[EMPTY PAGE]



FINAL INSTALLATION AND MAINTENANCE:

Clean grease spots off all exhaust system surfaces, when installation is finished. Cleaning will prevent spots from burning onto the surface. Do not use aggressive chemical cleaners, because they can damage the surface or sticker.

- 1. Muffler titanium outer sleeve: use a soft cloth sprayed with a multi-purpose spray lubricant (WD-40[®] or equivalent)*.
- 2. Muffler carbon-fiber outer sleeve: use a soft dry cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
- 3. Muffler carbon-fiber outlet cap: use a soft dry cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
- 4. Painted mufflers and parts use a soft cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
- 5. Chrome plated mufflers and parts: use a soft cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
- 6. Stainless steel pipes: use a soft cloth sprayed with a contact cleaner, then wipe with a soft dry cloth.
- 7. Titanium pipes: use a soft cloth sprayed with a multi-purpose spray lubricant (WD-40[®] or equivalent)*.

Periodically make sure all the bolts and springs are sufficiently tight.

- IMPORTANT: make sure all the bolts are sufficiently tightened. In case the exhaust system touches the cowling or other parts repeat the adjustment of the exhaust system or contact your authorized dealer!
- CAUTION: after running engine for 30 minutes, retighten the bolts of the Akrapovič carbon-fiber heat shield!
- INSTALLATION TIP: IT IS NORMAL IF WHITE SMOKE COMES OUT OF THE MUFFLER DURING THE FIRST 100 KM AFTER REPLACEMENT.
- INSTALLATION TIP: A CHANGE IN THE COLOR OF THE EXHAUST SYSTEM IS NORMAL DUE TO THE HIGH TEMPERATURES.
- CAUTION: DO NOT STAND BEHIND THE MUFFLER AT ANY TIME.
- IMPORTANT: DO NOT USE AUTOMOTIVE WHEEL CLEANERS OR ANY CLEANING PRODUCTS WHICH CONTAIN ACIDIC ADDITIVES TO CLEAN AKRAPOVIČ EXHAUST SYSTEMS.

^{*}WD-40[®] is a trademark of the WD-40 Company.

TROUBLESHOOTING:

Problem	Possible cause	Solution
Exhaust gas leaks out of the muffler/pipe clamp connections	loosened clamp	tighten the clamp to specified torque
	connection is not completely joined	tap the connection into place and tighten the clamp to specified torque



