

## **Kit Contents**

Description	Part No	Pcs
Shock absorber	YA 427	2
Tool pre-load adj. cruiser	03199-03	1
Seal ball joint	00534-02	8
Bolt M10x1.25x30	00439-18	1
Spacer Ø14x20	01218-36	2
Spacer Ø14x20	01218-54	6
Sticker set Öhlins	10207-01	1
Sticker memo notes	01180-01	1
Owner's manual	07241-02	1

## Mote!

Please note that this image is a general representation of the product and may differ slightly from your product.

## Mote!

Please note that during storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may leak and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/grease with a cloth.

## Mote!

Before installing this product, check the contents of the kit. If anything is missing, please contact an Öhlins dealer.

## Warning!

Before installing this product, read the Öhlins Owner's Manual. The shock absorber/front fork/steering damper is an important part of your vehicle and will affect the stability.

# Shock absorber for Yamaha V-Max



# **Mounting Instructions**



# MOUNTING INSTRUCTIONS

## Warning!

It is advisable to have an Öhlins dealer install the shock absorber/front fork/steering damper.

## Warning!

If working on a raised vehicle, ensure it is securely supported so that it will not tip.

### W Note!

Before mounting this product clean the vehicle thoroughly.

## Mote!


When working on this product, always see the Vehicle Service Manual for vehicle specific procedures and important data.

### 1

Put the motorcycle on a workstand so that the rear wheel barely touches the ground.

Loosen and remove the original shock absorbers. Consult your motorcycle workshop manual for advice

Remove the original bracket bolt from the brake caliper and use the allen bolt (00439-18) provided in this kit.



Install the Öhlins shock absorbers in the same position as the original units. The cylinder heads upwards and the piggy back reservoirs backwards. Install the spacers provided in this kit. See figures.

## Caution!

There is a left hand and a right hand shock absorber. The reservoir mount is angeled slightly outwards to the left and to the right side. If the shock absorbers are installed with the reservoirs angled towards the wheel they can be damaged.


## Mote!

Lower the vehicle so that the suspension is slightly compressed before tightening the screws.

## 🕒 Caution!

Ensure that all screws are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber/front fork/steering damper when the suspension is fully compressed or extended.


# **MOUNTING INSTRUCTIONS**



# **ADJUSTMENTS**


## **A** Warning!

Before riding, always make sure that the basic settings made by Öhlins are according to recommended Setup Data. Read about adjustments and setting up in the Öhlins Owner's Manual before you make any adjustments. Contact an Öhlins dealer if you have any questions about setting up.



## **△** Warning!

The adjustable end eye/bracket must not be threaded out more than that the groove is fully visible beneath the lock nut. This is maximum length. After adjusting, make sure that the lock nut is tightened (30Nm).



# **SETUP DATA**

### Recommended set-up

### Spring

 Part No
 60360-05

 Free spring length...
 200 mm

 Spring rate......
 18-20 N/mm

 Preload adj.range...
 [0-36] mm

## Shock absorber data

Öhlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur. To find the latest information contact an Öhlins distributor.

Please contact Öhlins if you have any questions regarding the contents in this document.

Part no. MI\_YA427\_7 Issued 2018-10-18

© Öhlins Asia Co. Ltd. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited.

Öhlins Asia Co. Ltd 700/937 Moo5, Tambol Nongkhaga, Amphur Phantong, Chonburi Province 20160 Thailand

